Contents, Bombing and Gunnery Range General Layout Information

Layout of a Low Angle Strafe Targets



Front View of Strafe Pit



Top View of Strafe Pit



Layout of a Drag Chute Target, Front View



Layout of a Drag Chute Target, Side View



Relationship Layout of a Target Transducer



Transducer Installation Layout



NOTE: For 7.62mm firing, transducer top will be set 6.5 inches below top of the berm. The firing of 20mm and 30mm with the 6.5 inch transducer setting is permissible. However, if only 20mm and 30mm is being fired, the 8.5 inch setting is recommended.